
User Guide Evaluation Kit for TFT 10.1" panel with CTP

WF101-1280800LL#0SP3-FC



WWTFTDEMO101L-11# (kit)



Kit Assembling Guide

1) Connect the TFT display module to the RA8877 control board (a) through SW100*** transfer board (a) via FPC 40pin
2) Connect RTP to RA8875 control board (a) via RTP cable 4pin
4) Connect the RA8877 control board (a) to the WWPIC24F-A-00# (d) via FFC 36pin (c) between bottom contact ZIF connectors 36pin
5) Insert 5V/1A power adapter (e) to the WWPIC24F-A-00# (d) through power jack connector
3) Connect the B/L cable of the display module to WWLEDDRIVER-101-0# LED driver (f) via B/L cable 2pin
5) Insert 5V/2A power adapter (g) to the WWLEDDRIVER-101-0# (f) through Anode and Cathode Pins
6) Power ON through Power ON/OFF switch on the WWPIC24F-A-00# (d)